

Board and Batten | Installation Instructions

Tools required for Wood, Composition, Metal and Vinyl Siding:

Drill, 1/8" Drill Bit, Phillips Screwdriver

Tools required for Brick, Stone and Other Masonry:

Drill, 1/4" Carbide Drill, #8 x 1" Masonry Anchors, Phillips Screwdriver

Hardware:

Screws (Bag of 12), Shutter Board, Batten



Figure 1



Figure 2



Figure 3

STEP 1:

Place shutter next to the window in the desired location. Mark holes on the wall using the vertical slots on the shutter as a guide. If installation is occurring on masonry or brick, locations should be in line with mortar joints. (see Figure 1)

STEP 2:

Remove shutter from the wall. Drill 1/8" holes 2" deep into the wall surface. Make certain no electrical wires or pipes are in the wall where holes are to be drilled. If installing screws in masonry, use 1/4" carbide drill bit to drill holes in mortar joints and use masonry anchors. (see Figure 2)

STEP 3:

Hold shutter in position and secure in place using screws provided. Place screw through the vertical slot on the shutter and tighten the screws only until the heads are flush with the surface. Do not over-tighten. (see Figure 3)

STEP 4:

Snap battens onto the shutter to conceal screws.

Painting Shutters

If you wish to change the color of your shutters, simply prime them with a paint designed for painting plastics.

Note: The above instructions are used for all Board-n-Batten shutters.