

ALPHA SYSTEMS LLC.

Self-Locking Rubber Compression Fitting Kit

Installation Instructions

1. Drill the appropriate hole size for the rubber grommet being installed.
Clean the area around the hole to ensure there are no plastic shavings remaining.

1 ½” grommet requires 2 ½” hole size
2” grommet requires 3” hole size
3” grommet requires 4” hole size

2. Install the grommet using hand pressure only, The grommet should fit tight into the hole.
3. To install the self-locking coupler, spray the end of the coupler with soapy water before installing in the rubber grommet. This will make it easier to install the coupler into the grommet. Be sure the coupler is locked into the proper position. The water will evaporate leaving a firm dry fit. **DO NOT USE ANY SILICONE BASED PRODUCT** as it will not evaporate.

