



TUFF-PLY MARINE FLOORING CLEANING **INSTRUCTIONS**

To clean the TUFF PLY marine flooring first use low sudsing soap like SPIC AND SPAN, SIMPLE GREEN, or 409. If the boat is being cleaned while it is in a body of water an environmentally safe detergent should be used. Scrub using a rag, sponge or soft bristle brush. Rinse thoroughly with water.

A power washer may also be used with a fanned tip and a maximum pressure of 1500 psi. Avoid direct contact around attachment areas and protrusions through the floor to prevent the pressurized water from forcing its way under the flooring. Most dirt can be removed using the power washer without soap but tougher stains may require a soap and rinse cycle.

For extreme stains or spills, please contact Alpha Systems, LLC for further cleaning instructions.